



WayteQ N710B GPS Navigator

User Manual

English Version

NOTICE

USING YOUR NAVIGATOR at the first time

1. Charge completely
2. Install into your vehicle
3. Initialize software as described in the manual
4. Make sure that the car is outside the garage and it is not covered by anything (treed, bridges, etc)
5. Normally it takes a bit longer to receive the GPS signal the first time you turn on the unit. Your device has to locate 3 satellites to function. This time to find the satellites is significantly shorter after the first time you use the device. If you move your unit over 300km without it being used, it may need a little more time to locate the satellites again.

Introduction

This manual is a complete instruction for the device. Please read this manual carefully before using.

Contents:

Safety and Regulatory Information

1. Getting Started

- 1.1 Unpacking
- 1.2 Over View
- 1.3 Using Your Device in a Vehicle
 - 1.3.1 Using the Car bracket
 - 1.3.2 Connecting the Car Charger
 - 1.3.3 Connecting to AC Power supply and Charging the Battery
 - 1.3.4 Assembly
- 1.4 Starting up
- 1.5 Power saving

2. Main Menu Selection

- 2.1 Navigation
- 2.2 Music
- 2.3 Photo
- 2.4 Ebook
- 2.5 Video
- 2.6 System

3 FREQUENTLY ASKED QUESTIONS

- 3.1 I can't find an address
- 3.2 There is a failure in the map / POIs are missing
- 3.3 Voice instructions are unclear in a specific situation
- 3.4 I have problems to get a GPS fix
- 3.5 Where can I get technical support?
- 3.6 Where can I get software updates?
- 3.7 Where can I get additional maps and guides?
- 3.8 How to Install the MS ActiveSync?
- 3.9 How to download the files from the website and put in my SD Card?
- 3.10 What Kind of Formats Does The Device Support?

4. Connecting to Your PC

5. Troubleshooting and Maintenance

- 5.1 Resetting Your System
- 5.2 Troubleshooting
 - 5.2.1 Power Problems
 - 5.2.2 Screen Problems
 - 5.2.3 Connection Problems
 - 5.2.4 GPS Problems
 - 5.2.5 Voice Too Small Or No Voice

5.2.6 Why can not use my download files (Option)

5.3 Maintaining Your Device

6. Battery, Charger and Safety Precaution

6.1 About Charging

6.2 About the AC Adapter and the Car Charger

6.3 About the Battery

7. Specifications

Safety and Regulatory Information

Important Safety Notices and Warnings

Global Positioning System

The Global Positioning System (GPS) is a satellite-based system that provides location and timing information around the Globe.

GPS is operated and controlled under the sole responsibility of the Government of the United States of America, who are responsible for its availability and accuracy. Any changes in GPS availability and accuracy, or in environmental conditions, may impact the operation of your device. We cannot accept any liability for the availability and accuracy of GPS.

Precautions and Notices

For your own safety, do not operate the controls of the product while driving.

Use this product prudently. The product is intended to be used only as a navigation aid. It is not for precise measurement of direction, distance, location or topography.

The calculated route is for references only. It is the user's responsibility to follow the traffic signs and local regulations along the roads. When you get off the car, do not leave your device on the dashboard or the car glass that is subject to direct sunlight. The overheating of the battery can cause malfunction and /or danger.

GPS is operated by the United States government, which is solely responsible for the performance of GPS. Any change to the GPS system can affect the accuracy of all GPS equipments.

GPS satellite signals can not pass through solid materials (except glass). When you are inside a tunnel or building, GPS positioning is not available.

A minimum of 4 GPS satellite signals is needed to determine current GPS position. Signal reception can be affected by situations such as bad weather or dense overhead obstacles (e.g. trees and tall buildings)


The wireless devices might interfere the reception of satellite signals and cause the reception of the signal to be unstable. For better signal reception, it is recommended that you use a car antenna (option)

Aircraft and Hospitals

Use of devices with an antenna is prohibited on most aircraft, in many hospitals and in many other locations. The device must not be used in these environments.

1. Getting Started


1.1 Unpacking



Unpack your device box and identify the contents. You should have:

- (1) Unit. Its main features are a touch-sensitive LCD screen, 1 SD card slot, 1 volume control switch. Details see the photo below.
 - (2) Holder, to hold the device.
 - (3) Bracket, its main features is to fix the device on a car .
 - (4) Car Charger. With 12V cigarette lighter adapter. This is the normal way of providing power to your device when it's in your vehicle.
 - (5) AC adapter (Option), included for you to charge and work with your device even when It's not in your vehicle. When you use the adapter, please make sure it is cooled by placing it in a ventilated area.
 - (6) USB data cable for connecting your device to a Windows PC
 - (7) GPS External Antenna (Option) is used when the GPS signal is not so strong and it should mounted on the top of the car or on the front of the car window .
 - (8) SD card(Option), containing map data.
 - (9) User Manual.
 - (10) Installation CD (Option), containing PC connection software and extra maps.
- *Note: please check optional accessories with local retailer/importer/distributor.

1.2 Over View



- (1) Charger Indicator Light
- (2) Saving Power Switch
- (3) Unit Power On/Off
- (4) GPS Antenna
- (5) Speaker
- (6) SD Card Slot: for accessing data as maps. Note:
Before using GPS navigation software and maps, you need to insert the storage Card included with your device. Do not remove the card during GPS operation.
- (7) Earphone Jack
- (8) Reset Key
- (9) USB Connector
- (10) External GPS Antenna Connector
- (11) Volume Switch
- (12) DC Jack

Do not expose the device to high temperatures. We recommend that you do not leave the device in direct sunlight for long periods or in an unattended car on sunny days.
High temperatures can cause permanent damage.
Do not attempt to service the device yourself! Do not open, puncture or disassemble it.
Doing so may be dangerous and will invalidate your warranty.

1.3 Using Your Device in a Vehicle

A stand and a car charger are supplied with your device.

1.3.1 Using the Car Bracket

Caution:

- Select an appropriate location for the stand. Never place the stand where the driver's field of vision is blocked.
- If the car's windshield is tinted with a reflective coating, an external antenna (optional) maybe be needed to route the.
Antenna to the top of the car through a window. When closing the car window, be careful not to pinch the antenna cable (Cars with an anti-jam window design may automatically leave adequate space as needed.).



1.3.2 Connecting the Car Charger

The car charger supplies power to your device when you are using the device in a car.

Caution: To protect your device against sudden surges in current, connect the car charger only after the car engine has been started. Connect one end of the car charger to the power connector of your device. Connect the other end to the cigarette lighter in the car to power and charge your device.



To Cigarette Lighter
1. Device power connector
2. Vehicle power connector

1.3.3 Connecting to AC Power supply and Charging the Battery

1. Fully charge the battery before using your device for the first time
2. Connect the adapter cable to the bottom of your device.
3. Plug the AC adapter into a wall outlet.



The charge indicator glows amber when charging is in progress. Do not disconnect your device from AC power until the battery is fully charged, when the charge indicator turns green. This will take a couple of hours.

1.3.4 Assembly

To get started, put the device into the holder and assemble holder with bracket. Take off the

protected film on the bottom or the suction. Then put the bracket onto a suitable location of your windscreen or side window, make sure the window or the suction or windscreen is clean and without water and some dirty things inside, fixing the stand on that position..

Note: Controlling 5 different levels of suction by pressing down the button (See below picture)



Controlling 5 different levels of suction by pressing down the button

Note: that some newer vehicles may have a heat reflective shield embedded in the windscreen. In some cases this can prevent proper GPS signal reception. If this turns out to be a problem in your vehicle, you will need to purchase and install the GPS external antenna kit.

Under normal journey conditions, the suction mount is perfectly sufficient to hold the bracket in position. Note that suction may be lost if left overnight, due to condensation and low temperature. For this reason, and for security, we recommend Removing Both the suction mount bracket and the device when leaving your vehicle overnight.

To remove the bracket, three steps as below:


Press 2 sides button, pull back lightly and then take off the suction. If the bracket still doesn't detach from your windscreen, tug gently on the clear plastic tab at the edge of the suction mount, to break the vacuum seal.



- 1. Press 2 sides button**
- 2. Pull back lightly**
- 3. Take off the suction**

1.4 Starting up

Push the System Power button to the "ON" position, when first time to use, and leave it on "ON" position.(Suggestion: please leave it on "OFF" position if long time not use.)



Insert the supplied SD card(optional) into the slot at the bottom of device.




Tap "OK" then enter into the "Main Function Operation Screen" as below.




Then select the functions you need and then go directly to the way you need.

1.5 Power saving

Press the power button  on the top side of your device to turn on and off your device for saving power. When you press the power button to turn off the unit, your device actually enters a suspend state and the system stops operation. Once you turn on the system again, it resumes.

2.Main Menu Selection

Main Menu is the start of all functions. It includes two or six function icons such as navigation, Music with Mp3,Photo,Ebook,Vedio player with MP4,and system setting .You can choose your desired functions as you like.




2.1 Navigation

Please refer the navigation software user manual for the details.

2.2 Music


1) Tap the icon "Music" on the main menu and enter into following display.



2) Tap your desired file and enter into the following display.

It supports various player format. Please refer to DOWNLOAD AND UPDATE.

If no Mp3 files can be found, it will enter into playing directly.



- | | | |
|------------------------|----------------------------|---------------|
| A: Return to main menu | E: Return to previous Menu | I: Speed bar |
| B: Circle | F: Next | J: Pause/play |
| C: Auto play | G: Previous | |
| D: Volume control | H: Stop | |

3) Tap "  " and return to the main menu,

2.3 Photo

1) Tap " Photo" on the main menu and enter into the following display



2) Tap the file on the screen and enter into the following picture.



- A:previous
- B:next
- C:return to previous menu
- D:current picture name
- E:Zoom out
- F:Zoom in
- G:rotate
- H:full screen

3)Tap " ✕ " and return to main menu.

Tips:

Tap FULL SCREEN button, it will display in full screen size




Tap PREVIOUS or NEXT button to view the pictures.


If picture is too big or the device does not support the format,it will be dark screen or can not read.



2.4 Ebook



2) Tap the file on the picture and enter into the following display.




- A:Return to main menu
- B:Previous
- C:Next
- D:Return to previous menu
- E:Pages chose
- F:Current page/total pages
- G:Current file name

3) Tap " X " and return to main menu.

2.5 Video Player

1) Tap the icon "Video" on the main menu and enter the following display.



2) Tap the file and enter into the following display.

It supports various player format, please refer to DOWNLOAD AND UPDATE.



- A:Return to main menu
- B:Pause/play
- C:Stop
- E:Volume control
- D:Next
- F:Full screen
- G: Return to previous menu
- H:Speed bar

3) Tap " ✕ " and return to main menu.

Tips:

Tap NEXT button to recircle the movie.

Tap full screen button or double press the screen, it will play in full screen.




When playing in full screen, double press the screen again, it will return to original playing size.



2.6 System

Tap the icon "System" on the main menu and enter into the following setting.



- A: return to main menu
- B: volume
- C: power
- D: backlight
- E: date and time
- F: language
- G: system information

1) Tap the icon "Backlight" and enter into the following display.



- A. Under BACKLIGHT icon, tap - to weaken the backlight, tap + to stronger the backilght.
- B. Under battery icon, tap < or > button to select the duration of auto power off the backlight.
- C. Under AC power icon, tap < or > to select the duration of auto power off the backlight when using AC adaptor.

2) Tap the icon "Sys Info" and enter into the following display



A:Factory setup


B:GPS reset

C:Calibration

Tap "Calibration" and enter the adjustment of touchscreen

According to the information on the screen,press the right cross centre

Then take the operation under instruction until the following screen display.



3) Language


A)Tap the icon "Language" and enter into the following display.



B) Tap "<" or ">" icon to select the language or color display.


4)Power

Tap the icon "Power" and enter into following display.



5)Volume

- A) Tap the icon "Volume" and enter into volume setting display.
B) Tap "-" or "+" to adjust volume of speaker.



6) Date and Time

- A) Tap the icon "Date and Time" and enter into the following display.



- B) Tap DATE icon and use < or > icon to adjust the date.



- C) Tap TIME icon and use < or > icon to adjust the time.



3.0 FREQUENTLY ASKED QUESTIONS

3.1 I can't find an address.

Please make sure you have correctly spelled your entry. If you do not know how an address is spelled correctly, simply enter the parts of the address, you know for sure (e.g. "Lond", "Leic" for Leicester Square in London). Then browse in the result list and look for the address. Also make sure that the city in which you are looking for an address is correct.

Sometimes the official postal address differs from the address you are looking for. In that case, search for an address nearby that you know of and browse on the map.

If you find the address on the map but you can not find it while searching for it, please contact the manufacturer or your retail know of and browse on the map.

Store for information about software updates.

3.2 There is a failure in the map / POIs are missing.

If you detect an error in the map data (e.g. a street is missing completely), we would like to inform our map data provider.

Please contact the manufacturer or your retail store for information about software updates.

3.3 Voice instructions are unclear in a specific situation:

If you could not fully understand the voice command for a manoeuvre, either hit the repeat command button or ask your companion to take a look at the map.

3.4 I have problems to get a GPS fix.

If you have problems getting a satellite fix with the GPS (you can see how many satellites are being received on the main menu at the bottom left) please make sure, that you are outside and the GPS antenna has a good visibility to the open sky.

Some models also do support an additional external active antenna. Please also consult with the hardware manual of your device to get further information of how to obtain a GPS fix.

3.5 Where can I get technical support?

Please contact the manufacturer or your retail store.

3.6 Where can I get software updates?

Please contact the manufacturer or your retail store for information about software updates.

3.7 Where can I get additional maps and guides?

Please contact the manufacturer or your retail store for information about software updates.

3.8 How to Install the MS ActiveSync?

ActiveSync allows you to establish a connection and transfer files (i.e.MP3 Files) between your device and your computer

Caution: Do not connect your device to your computer before ActiveSync is installed.

Down the "Ms ActiveSync" from below website:


www.microsoft.com/windowsmobile/downloads/activesync42.msp

Step1: Turn on your PC and your device , then connect them by the supported USB cable.


Step2: After Wizard display, press "NO" and then press "Next".



Step3: Tap "Explore" button.



Step4: Copy the Map file to the "Cities" file of SDMMC folder.




3.9 How to download the files from the website and put in my SD Card?

Step1: Turn your PC and your device, then connect them by USB cable.


Step2: After Wizard display, press "NO" and then press "Next".



Step3: Tap "Explore" button.



Step4: Enter into the MEDIA file of the SDMMC



Put Music files to the MP3 Directory

Put Movie files to MP4 Directory

Put photos and pictures in the Picture Directory

Put the web files to TEXT Directory

Put the map in the Cities Directory

3.10 What Kind of Formats Does The Device Support?

Support Music Format: MP3、WMA、WAV

Support Movie Format: AVI、DVIX、XVID、WMV、ASF、MPEG1、MPEG2

Support Picture Format: JPEG、BMP、GIF、PNG

Support E-Book Format: TXT

4. Connecting to Your PC

Two ways to update or change the maps, the software, the multi-media files to your device. You'll probably want to link it to Your PC.

1: Using The Card-reader

1.1 Insert the SD Card to the card-reader and USB cable to connect with PC.

1.2 Copy the update maps/software/multi-media files to the correct file Route on your SD Card

1.3 Take out the SD Card from the card-reader and insert to your device.

1.4 The device will show you the contents of the SD Card and press the functions and go .

2: Using MS ActiveSync software

2.1 Set up the MS ActiveSync on the PC (See 3.8 How to install the MS ActiveSync?)

2.2 Connect the device and PC via USB cable

2.3 MS ActiveSync will run automatically once the device connect with PC(But make sure the device is power on)


2.4 Put the map/software/multi-media files to the correct file Route on SD Card

***Remarks: Map and software update must do according to software user manual

5. Troubleshooting and Maintenance

5.1 Resetting Your System

Resetting your system is similar to restarting your computer. Occasionally, you may need to reset your device. For example, you should reset your system when it stops responding or appears to be "frozen" or "locked up". To reset your system, press the Reset button on left side of your device.



If your device still does not respond after being reset, you can use the following steps to clear the memory, and reset the system settings to factory defaults.

Disconnect all cables, including the AC Adaptor, from your device.

Use the stylus pen or your finger to slide the ON/OFF switch to the OFF position.

Wait for 1 minute and then slide the switch back to the ON position.

Your device will automatically turn on and the Main screen will appear.

Note: Once you clear the memory with this ON/OFF switch, all the settings you have changed in the System Settings will be erased, you need to re-enter any personal settings, including time and date once again.

5.2 Troubleshooting

5.2.1 Power Problems

Power does not turn on when using battery power

- > Make sure the power switch is already in ON position
- > The remaining battery power may be too low to run your device.
- > Connect the AC adapter to your device and to AC power or Connect the Car Charger to your device and to external DC power.

5.2.2 Screen Problems

A) Screen is off

If the screen does not respond even after you press the power button, try the following in order until the problem is solved:

- > Connect the AC adapter to your device and to external AC power.
- > Connect the Car Charger to your device and to external DC power.
- >Reset your system.

B) Screen responds slowly

Make sure that your device is not running out of battery power.

C) Screen freezes

Reset your system.

D) Screen is hard to read

Make sure that the power is enough

Make sure that the backlight of the display is on

Move to a location with more light

If the problem still exists, reset your system.

E) Inaccurate response to stylus pen taps or finger tip

Recalibrate the touch screen.

5.2.3 Connection Problems

Cable Connection Problems

> Make sure that your device and your computer are both turned on before trying to establish a connection.

> Make sure that the cable is securely plugged into the USB port on your computer and on the device. Connect the USB cable directly to your computer

> Reset your device before connecting the cable. Always disconnect your device before you Restart your computer.

5.2.4 GPS Problems

When there are no valid signals available, consider the following:

> Make sure that the GPS antenna is adjusted to the horizontal position (parallel to the ground) and it has a clear view of the sky.

> Note that the GPS reception can be affected by:

- Bad weather.
- Dense overhead obstacles (e.g. trees and tall buildings).
- Other wireless device in the car.
- Reflective car window tint.

5.2.5 Voice Too Small Or No Voice

If the earphone is in the earphone jack, the speaker will be w/o voice, take the earphone from the unit, then the voice out comes Rotate the Volume Switch to the + position and upwards

Check the Sound Set on your System ,make sure your voice setting is correct and the voice volume is big or not

5.2.6 Why can not use my download files (Option)

The file format is not supported

The file is not in the correct Route

MP3 Route is as : SD card \media\mp3

MP4 Route is as SD card \media\mp4

JPG,BMP files Route is : SD card \media\pic

Map and navigation Voice is: SD Card \Cities\...

5.3 Maintaining Your Device

Taking good care of your device will ensure trouble-free operation and reduce the risk of damage to your device.

- > Keep your device away from excessive moisture and extreme temperatures.
- > Avoid exposing your device to direct sunlight or strong ultraviolet light for extended periods of time.
- > Do not place anything on top of your device or drop objects on your device.
- > Do not drop your device or subject it to severe shock.
- > Do not subject your device to sudden and severe temperature changes. This could cause moisture condensation

Inside the unit, which could damage your device. In the event of moisture condensation, allow the device to dry out completely before use.

> Take care not to sit on the device. We advise not to carry the device in one*s back pocket for that reason.

> The screen surface can easily be scratched. Use the stylus or your fingers tap on the screen. Avoid touching it with any sharp objects. Non-adhesive generic screen protectors designed specifically for use on portable devices with LCD panels may be used to help protect the screen from minor scratches.

> Never clean your device with it powered on. Use a soft, lint-free cloth moistened with water to wipe the screen and the exterior of your device.

> Do not use paper towels to clean the screen.

> Never attempt to disassemble, repair or make any modifications to your device.

Disassembly, modification or any attempt at repair could cause damage to your device and even bodily injury or property damage and will void any warranty.

Do not store or carry flammable liquids, gases or explosive materials in the same compartment as your device, its parts or accessories.

6. Battery, Charger and Safety Precaution

6.1 About Charging

> Use only the AC adapter and the DC Car Charger supplied with your device. Use of another type of AC adapter or Car Charger will result in malfunction and/or danger.

> The AC adapter input rated 100~240V AC,50/60Hz, 0.35A, output rated +5V DC / 2.0 A,DC Car Charge input rated DC input 12V DC output 5V, 2A.

> Use a specified Lithium-Lion battery in the equipment.

6.2 About the AC Adapter and the Car Charger

> Do not use the adapter or the car charger in a high moisture environment. Never touch the adapter when your hands or feet are wet.

> Allow adequate ventilation around the adapter or the car charger when using it to operate the device or charge the battery. Do not cover the AC adapter or the car charger with paper or other objects that will reduce cooling. Do not use the AC adapter while it is inside a carrying case.

> Connect the AC adapter to a proper power source. The voltage requirements are found on the product case and/or packaging.

> Do not use the adapter or the car charger if the cord becomes damaged.

> Do not attempt to service the unit. There are no serviceable parts inside. Replace the unit if it is

damaged or exposed to excess moisture.

6.3 About the Battery

> Use a specified charger approved by the manufacturer.

CAUTION: This unit contains a non-replaceable internal Lithium Ion battery. The battery can burst or explode, releasing hazardous chemicals. To reduce the risk of fire or burns, do not disassemble, crush, puncture, or dispose of in fire or water.

> Important instructions (for service personnel only)

- Replace only with the same or equivalent type recommended by the manufacturer.。

- The battery must be recycled or disposed of properly.

- Use the battery only in the specified equipment.

CAUTION: Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

7. Specification

CPU: Samsung SC-2440A

SDRAM: 64M Bytes

ROM: 32/64 MB NAND Flash

Display: 4.3" TFT LCD with Touch Panel, resolution 480 x 272

Map storage: SD/MMC Card

USB Device: USB 1.1

OS: Microsoft Windows CE.NET 4.2

Working temperature: 0~60oC

Storage temperature: -20oC~80oC

Power: 5V, 2A